

ASSEMBLY INSTRUCTIONS

1. Attach "loading bay" side to the two end walls. Fix the platform wall to the platform top against the lip on the underside. Next, fix the whole platform inside the loading bay.
2. Fit the three larger windows into the remaining side wall and attach that wall to the ends. The Square "loading bay" sliding doors may be fitted as desired inside the wall. (The planks should be vertical.)
3. Rail entrance doors may be attached to the edges of the end wall entrances if required.
4. Fit the main roof parts to the building. Attach the weather boards under the loading bay roof projections.
5. Fit the windows and door into the office walls. Assemble the office and glue the plain wall to the main building.
6. Assemble the office roof by joining the two sides together at the ridge, glue in the triangular piece and fit to the top of the office.

All normal polystyrene cements are suitable for assembling this kit.

MADE IN THE UK