

Bachmann Quarry Hunslet Sound Function List

- F1 - Sound - On/Off
- F2 - Brake
- F3 - Cylinder Drain Cocks
- F4 - Bell Whistle (Speed Related)
- F5 - Reverser
- F6 - On - Firebox Door Open / Off - Firebox Door Closed
- F7 - Coal Shovelling (only with F6 On)
- F8 - Blower
- F9 - Flange Squeal (Speed Related)
- F10 - Speed Lock
- F11 - Hand Brake (Functional)
- F12 - Water Tank Filling
- F13 - Coupling Clank
- F14 - Light Engine Mode
- F15 - Fade All Sounds
- F16 - Guard's Whistle
- F17 - Enable Auto Wagon Buffering
- F18 - Injector
- F19 - Alternative Whistle (Speed Related)
- F20 - Shunting Mode
- F21 - Safety Valves Lined
- F22 - 'Clear my side'
- F23 - 'Red light ahead'
- F24 - 'Coal on the fire'
- F25 - Volume Down
- F26 - Volume Up

Analogue Users: Please note that normal load running sounds, acceleration steam chuff sounds and any other automatic and randomised sounds will also operate when this model is used on analogue control (DC) straight from the box!