




# Class 55 V2/V3 PARTS DIAGRAM

Part no.	Part Name	Quantity	Part no.	Part Name	Quantity
5	SIDE_WINDOW	2	16	16_STEP_UNDER_DOOR_R	2
6	SIDE_WINDOW_R	2	17	17_BUFFER	4
3	3_CLEARPART_CABIN_FRONT	2	19	ROOF_GRILL_CL_55	4
4	4_CLEARPART_CABIN_FRONT_R	2	29	29_WIND_SCREEN_WIPER_R_LARGE	2
7	7_CLEARPART_ENGINE_ROOM	12	30	30_WIND_SCREEN_WIPER_L_LARGE	2
10	10_HANDRAIL_SMALL_FRONT	2	31	31_WIND_SCREEN_WIPER_R_SMALL	2
11	11_HANDRAIL_SMALL_CORNER_L	2	32	32_WIND_SCREEN_WIPER_L_SMALL	2
11	11_HANDRAIL_SMALL_CORNER_R	2	33	33_LAMP_IRON_SMALL_L	2
12	12_HANDRAIL_FRONT_VERTICAL_L	2	34	LAMP_IRON_LARGE_CENTER_FRONT_V2	2
12	12_HANDRAIL_FRONT_VERTICAL_R	2	35	LARGE_HORN_V2	2
13	13_HANDRAIL_DOOR_LARGE	8	36	SMALL_HORN_V2	2
14	14_HANDRAIL_DOOR_SMALL	8	102	PLATED_HEADCODE_V2	2
15	15_STEP_UNDER_DOOR_L	2	103	HEADCODE_LIGHT_BOX	2
107	BODY_NOSE_UNIT_V2	2	104	HEADCODE_LIGHT_BOX_LENS	2
			105	HEADCODE_LENSSES	2
			8	CLEARPART_HEADCODE_V2	2
			111	CORNER_STEP	4

Models are supplied with single or twin wipers, depending on loco and livery.



This model is designed for 'Plug and Play' DCC conversion using an ESU #58515 LokSound V5 XL decoder. Chassis has been designed to accommodate 2 x ESU smoke units if required.

Compatible with ESU 54678 Smoke Unit NOT INCLUDED

ESU 58515 V5XL Decoder NOT INCLUDED

Compatible with ESU 54678 Smoke Unit NOT INCLUDED

HI Lights only fitted on post-preservation V3 locomotives.


Part no.	Part Name	Quantity
97	192_BUFFERBEAM_PIPE_R_1	2
99	99_VACUM_PIPE	2
78	STEAM_PIPE_SOCKET_CL55_V2	2
79	STEAM_PIPE_CABLE_CL55_V2	2
81	AIR_CONTROL_PIPE_L	2
85	AIR_CONTROL_PIPE_R	2
86	ETH_RECEPTACLE_V2	2
87	MU_JUMPER_ADD_ON	2

### LIGHT SWITCHES:

- 1 - Tail Lights No1 end
- 2 - Tail Lights No2 end
- 3 - Cab lights both ends
- 4 - HI headlights both ends (V3 only)

Part no.	Part Name	Quantity
94	94_STEP_R	2
95	95_STEP_L	2
80	80_UPPER_STEP_BOGIE_STEP	4
46	46_STEP_IN_END	2
88	LED (Chain)	4
89	CHAIN_HANGER_L	2
96	CHAIN_HANGER_R	2

Fuel tank area is designed to accept up to two 66 x 29 mm speakers (not supplied) with locating pins provided. Remove 4 x screws shown to detach fuel tank bottom.



Remove these 4 screws to remove body