
DS8 - Stop-Caution Red-Yellow Digital DCC Signal

HANDLE WITH CARE - THIS MODEL IS NOT A TOY AND IS FRAGILE!

This signal incorporates a DCC decoder to enable it to be plugged or wired directly into the track and be controlled by any controller which is able to control DCC accessories. Please read these instructions before fitting your signal.



Bachmann tracks which have slots for a power clip. If you do not have this type of track or want to position your signal in a different place you can carefully cut off contact fingers where shown and connect wires from the 2 contacts



marked X to the nearest DCC track - it does not matter which way round the wires are connected. (NB Peco Streamline flexible track does have deep slots which can work by using packing under fingers)

Troubleshooting

Step 2 is the 'One Touch' DCC stage which programs the accessory address into the signal. If it does not work: · Check that one of the signal LEDs is lit - if not and locos etc run correctly on the same piece of track check the signal contact fingers are clean and tightly fitted between the track sleeper and rail - clean if necessary. • If a Signal LED is lit double check that your DCC controller is in accessory addressing mode - note that this is completely different to Locomotive addresses and will be explained in your controller instructions.

· Try fitting the signal to another section of track (or use pieces of wire to temporarily connect it to another track) If these steps fail contact your dealer or DCP support.

Signal design

This signal is our own design and tool and is based on colour light signals in North Norfolk. As well as a range of Digital signals you can also buy various kits based on this signal in 2, 3 or 4 aspect single and dual head designs with LEDs or a basic kit to add your own lights or make up as a dummy signal. Easy to use One-Touch™Digital Signal and Point controllers are also available.



www.train-tech.com



signals and/or points to work together to add basic automation to your layout which can also make it easier

to run and more realistic. For example you may wish to sync a Home and Distant signal together so that the Distant signal automatically changes with the Home signal before it. To do this you simply program both signals with the same DCC address which you can do either by touching the contacts on both signals then programming them at the same time, or doing each individually with the same address. Note that a Train-Tech Digital signal always goes to Green immediately after programming, making it easier to synchronise multiple signals as all signals have green. Similarly you could sync a Signal to a Point controlled by a Train-Tech DCC Point controller so that the signal is always red when the point is against it and green when it is clear to go. Again you can do this by programming the Point and Signal with the same DCC address.

Computer Control

Some DCC controllers can be connected to a PC to enable computer control of locomotives and accessories like this signal - for more details on what is compatible with your system consult your controller supplier.

Location board labels

These legends can be cut out and glued to the model Location board on the plastic detailing sprue. We suggest you use the DCC address you have programmed into your signal which will make the signal easier to identify and operate.

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100
AD	CA	DA	ES	ΕN	GE	GΥ	MΥ	ΡN	NW
AB	CDE	EFG	iHIJ	KLN	INC	PQ	RST	Ūν	WXYZ
ABCDEFGHIJKLMNOPQRSTUVWXYZ									


CONTROLLING YOUR SIGNAL

Control the signal by setting your controller to the DCC accessory address you chose and then send a 'direction' command from your controller to change the Signal colour (actual terms used for accessory control vary between controllers so please refer to the instructions)

(eg 65) \blacktriangleleft or \blacktriangleright = Red or Yellow

Your signal will retain the address you program it to unless you change it, which you can do at any time by following step 2 again.

Each signal head can have their own unique address or can be synchronised with other DCC signals or points etc by giving them the same address as each other - see details below.




Tip: The Location board can be used to show the DCC address of your signal to make it easier to identify while controlling your layout - you can cut out and glue the address from the table below

The signal is supplied with a kit of plastic parts for you to add extra details like ladder, handrails, phone and location board if you wish. These may be cut from the supports using small cutters or a knife on a cutting mat, but take care as these parts are extremely small and fragile, so we recommend using the following technique to remove them without damage.

We suggest you first remove ladder and main parts by carefully cutting the thicker supports first - after cutting these they should break away from the other parts by gently 'rocking' and you can then trim the fine supports. Parts may be cut from the supports using a knife on a cutting mat or by using precision cutters which can be invaluable for modellers - they are available from model shops or direct from us at www.dcpexpress.com You will also find that fine nose pliers or tweezers are useful both for cutting out and fitting parts. Parts can be glued in place using model adhesives such as Liquid poly or cynoacrylate 'superglue' etc.

We recommend first cutting the thicker supports to release main parts then trimming off the small supports




You can use the Location board (small square sign) to show the DCC address of the signal by cutting out and glueing the number from the table printed. You can also weather or paint the signal and add scatter material or ballast etc around the base and fingers, but take care not to cover the Learn or contact fingers and never let water or moisture get into base of the signal as this contains sensitive electronics.

Caution


This product is not a toy but a precision moulded model kit and as such has small parts which may choke or harm a child. Always take care when using tools, electricity, adhesives and paints, especially when children or pets are nearby.





- Works on N, TT, OO or HO Track
- Indicates the DC polarity, or DCC, or a fault
- Small enough to check point frogs
- **TT1 Track Tester**


One-Touch DCC[™] Signal Controllers



semaphore signals by DCC. Signals connect direct to the SC3 - no modifications or power supply needed.

Dapol Signals for photo - not included

Self Assembly Colour Light Signal Kits DC DCC



The LEDs are pre-fitted onto a long narrow PCB stick to pass through your baseboard. Just attach your signal control wires to PCB

• Every kit includes the head, post and base plus detailing kit inc ladder, handrails, etc Aluminium 'post' included with each kit

Control LED & Semaphore signals by DCC

Easy to set up & use -No CV programming!

Easy screw terminals - no soldering Can sync to other points & signals

SC1 Dual 2 aspect colour light signals controller

Controls one or two 2 aspect colour light signals.

most other manufacturer's LED signals

Compatible with Train-Tech SK2, SK3, SK7, SK8 and

SC2 3 or 4 aspect or 2 aspect+route signal control

Controls one 3 aspect or one 4 aspect or one 2 aspect

+ route signal. Compatible with Train-Tech SK4, SK5,

SC3 Dual Dapol 00/N Sempahore signal controller Controls one or two standard OO or N Dapol motorised

SK6 and most other manufacturer's LED signals

- Low cost adapt to your own design
- Control by switches or a signal controller General purpose signal kit:

SK1 Basic kit 2/3/4 aspect & dual heads - no LEDs

Signal kits with LEDs and resistors

SK2 Home 2 aspect kit with Red (R) Green (G) LEDs SK3 Distant 2 aspect kit with (Y) (G) LEDs SK4 Home Distant 3 aspect kit with (R) (Y) (G) LEDs SK5 Distant 3 aspect kit with (?) (G) (?) LEDs SK6 Outer Distant 4 aspect with R (G (G (Y) LEDs **SK7 Dual head Home** 2 aspect with (R) (G) LEDs SK8 Dual head Distant 2 aspect with (Y) (G) LEDs

SEE WWW.TRAIN-TECH.COM OR CONTACT DCP FOR FREE COLOUR BROCHURE



DS8 Stop - Caution Red • Yellow LED DCC clip-in signal

> Detailing kit included

• Signal plugs into track - just like a power clip! • Or connect 2 wires DCC Decoder in base

www.Train-Tech.com

See our website, your local model shop or contact us for a free colour brochure DCP Microdevelopments, Bryon Court, Bow Street, Great Ellingham, NR17 1JB, UK Telephone 01953 457800 • email sales@dcpmicro.com • www.dcpexpress.com



00

HO



